

Insights from the online LUS grain size gauge and the potential for future process control

Dietmar Hoppe¹, Thomas Haschke¹, August Sprock¹, Christoph Hassel¹, Joachim Hafer¹, Linda Bäck², Jan-Erik Thorberg², Christer Jonsson², Mikael Malmström³, Franziska Kneisel⁴, Matthias Bärwald⁴

¹SMS group GmbH, Hilchenbach / Düsseldorf, Germany

²SSAB EMEA AB, Borlänge, Sweden

³Swerim AB, Stockholm, Sweden

⁴EMG Automation, Wenden, Germany


Insights from the online LUS grain size gauge and the potential for future process control

Content

1. Introduction
2. Rolling trials & recalculations
3. Conclusion & outlook

Insights from the online LUS grain size gauge and the potential for future process control

Introduction – General overview of a typical HSM




- Current state
- Adherence to the set points in the process steps (rolling, cooling) very important
 - Deviations are corrected by control actions in the process models
 - No information about microstructure available

- New
- LUS device gives information about the microstructure (grain size, recrystallization and phase state,...)

Insights from the online LUS grain size gauge and the potential for future process control

Introduction – process data and microstructure evolution



Insights from the online LUS grain size gauge and the potential for future process control

Introduction - test installation and commissioning of LUS device at SSAB

Test
installation
at EMG



Commissioning
at SSAB



Insights from the online LUS grain size gauge and the potential for future process control

Rolling trials & recalculations – rolling parameters and materials

Online LUS grain size measurement



Evaluation of strips

Analysis as function of

- Material
- Thickness
- Finish Rolling temperature

Material:


- Low carbon (LC) steel
- LC – Nb steel
- Mn – Nb steel



Insights from the online LUS grain size gauge and the potential for future process control

Rolling trials & recalculations – results of recalculation

Strip 717043 (final thickness 3 mm, final width 1265 mm, final rolling temperature 890 °C)



RM

- Force
- Speed
- TB temperature

FM

- Force $F_1 - F_3$

FM

- Force $F_4 - F_6$


FM

- Final speed
- Final temperature
- Austenite grain size

— calculated — measured


Insights from the online LUS grain size gauge and the potential for future process control

Rolling trials and recalculations - measured and calculated austenite grain size




Insights from the online LUS grain size gauge and the potential for future process control

Rolling trials and recalculations - measured and calculated austenite grain size




Insights from the online LUS grain size gauge and the potential for future process control

Rolling trials and recalculations – measured and calculated austenite grain size



Insights from the online LUS grain size gauge and the potential for future process control

Rolling trials and recalculations – water amount calculation with CSC



ASTM	Grain size in μm	PA
4	100.00	978.66
5	70.71	931.71
6	50.00	884.77
7.2	33.00	828.42
8	25.00	790.87
9	17.68	743.92
10	12.50	696.97
11	8.84	650.02
12	6.25	603.08

Material	h mm	v m/s	T °C	1	2	3	4	5	6	7	8	9	10	11	12	Water m³/h	T °C
CMn	3.00	6.80	880	---	---	---	---	---	---	---	---	---	---	---	---	3127	597
CMn	5.00	4.50	880	---	---	---	---	---	---	---	---	---	---	---	---	3302	605
CMn	6.00	4.00	880	---	---	---	---	---	---	---	---	---	---	---	---	3652	599
CMn	9.90	2.50	860	---	---	---	---	---	---	---	---	---	---	---	---	3127	627

Current configuration state:
Grain size ~ 33 μm

Material	h mm	v m/s	T °C	1	2	3	4	5	6	7	8	9	10	11	12	Water m³/h	T °C
CMn	3.00	6.80	880	---	---	---	---	---	---	---	---	---	---	---	---	3127	600
CMn	5.00	4.50	880	---	---	---	---	---	---	---	---	---	---	---	---	3418	602
CMn	6.00	4.00	880	---	---	---	---	---	---	---	---	---	---	---	---	3652	602
CMn	9.90	2.50	860	---	---	---	---	---	---	---	---	---	---	---	---	3127	627

LUS measurement:
Grain size ~ 12 - 13 μm

- Temperatures slightly higher
- More water necessary

Insights from the online LUS grain size gauge and the potential for future process control

Conclusion

Roughing Mill RM and Finishing Mill FM:

- Very good agreement between measured and calculated austenite grain size:
 - Almost 77 % of the examined strips show deviations of $\pm 1 \mu\text{m}$
 - Further 21 % with slightly larger deviations of $\pm 2 - 4 \mu\text{m}$
 - Largest deviation of 6 microns has been detected for only one strip
- The reasons for the remaining deviations are subject to investigation:
 - Uncertainties partly exist in the recalculation of process data, especially at RM
 - Check of model approaches describing the microstructure simulation is in progress
 - Besides, strips with pronounced skid marks have to be investigated more in detail

Cooling Section Control CSC:

- Excellent model performance
 - Recalculations of CSC by using measured austenite grain size showed only minor changes in the coiling temperature
 - Only one strip with increased water volumes

Insights from the online LUS grain size gauge and the potential for future process control

Outlook

Next steps:

- Detailed analysis of open points
- Further rolling trials with new LUS device
- LUS measurements at additional positions (e. g. at furnace extraction, between RM and FM, before down coiler, ...)
- Improvement of L2 models
- Measurement of further properties like recrystallized fraction or ferrite grain size
- Integration of LUS device into L2 automation system
- Development of new rolling strategies

Thank You!